

CW-6300 INDUSTRIAL CHILLER

USER MANUAL



Contents

<1> Cautions-----	3
<2> Contour and parts introduction-----	4
<3> Installation-----	5
<4> Unit introduction and parameters adjustment-----	6
<5> Alarm and communication output-----	12
<6> MODBUS RS-485 communication function-----	13
<7> Specifications-----	17
<8> Simple troubleshooting-----	18



Thank you for using the machine from GUANGZHOU TEYU ELECTROMECHANICAL CO., LTD. Please read the installation instructions carefully before installing and operating and keep it properly.

This installation instructions is not a quality assurance. GUANGZHOU TEYU ELECTROMECHANICAL CO., LTD reserves the right to the interpretation of correction of typographical errors, improper mentioned information and product improvement. The amended content will be reprinted in installation instructions without notice in advance.

<1> Cautions

1. Please ensure that the power supply and electrical outlet are in good contact and the earth wire must be firmly grounded!
The water chiller installation must be done by professional person in order to avoid machine damage or accidents by misoperation.
2. Please make sure there is stable and normal voltage for the working chiller!
As the refrigeration compressor is more sensitive to the power supply and voltage, so the operating voltage of our standard product is $\pm 10\%$ of the rated voltage. If you do need a wider operating voltage range, customization is available for us.
3. Unmatched power frequency can cause the chiller damage!
Please choose model of 50Hz or 60Hz according to actual circumstance.
4. To protect the pump, it's strictly forbidden to run the chiller without water in the storage water tank!
The new machine is packed after draining whole water in the tank, so please make sure the tank has water inside before machine starting, otherwise it's easily to have the pump damaged. When the water level is below the green (NORMAL) range of the water level gauge, the cooling capacity of our chiller will go down slightly. Hence please ensure the water level is within the green (NORMAL) range. To drain through circulating pump is strictly prohibited!
5. Please be sure that the air inlet and air outlet are in good ventilation!
There must be at least 50cm from obstructions to the air outlet and at least 30cm between obstructions and the lateral air inlet.
6. Please pay attention to the effect of the condensate water!
With greater ambient humidity, when the water temperature is lower than the ambient temperature, the condensate water will generate on the surface of water circular pipes and the cooled components. If above circumstance appears, it is recommended to set a higher water temperature or keep pipes and cooled parts warm.
7. Please do turn on the chiller first before turn on the laser machine; turn off the laser machine first before turn off the chiller.
8. This product is an industrial equipment. For professional use only!

<2> Contour and parts introduction



<3> Installation


It is very simple to install this industrial cooling machine. The installation for the first time of the new machine can be carried out by following steps:


1. Open the package to check if the machine is intact and all the necessary accessories are completed.
2. Open the water supply lid to feed cooling water.
Observing the water level gauge to feed water slowly, be careful not to have the water overflowed!
3. According to system conditions, please connect the water inlet and outlet pipe properly.
4. Plug in power, turn on the power switch. (Do not start up without water in the water tank!)
 - (1) The water pump starts working once the power switch is turned on. If “E05” error code is displayed on the upper window of temperature controller, please adjust the 3-phase wiring connection order
 - (2) The first running of the chiller may have flow alarm because of bubbles in the water pipe. It will recover to normal after water pump running constantly for a while.
 - (3) If the chiller starts for the first time, you must immediately check whether the water pipe leaks.
 - (4) Power switched on, if the water temperature is under the set value, it is normal that fans and other components of the machine do not work. The temperature controller will automatically control the working conditions of the compressor, magnetic valve, fans and other parts based on the set controlling parameters.
 - (5) As it takes a longer time to start over the compressor and other components, according to different conditions, the time is range from seconds to minutes, so do not turn on and off frequently.
5. Check the water level in the water tank.
The first starting up of a new chiller will empty the air in the water pipe, causing a slight water level decline, but in order to keep the water level in the green area, it is allowed to add adequate water again. Please observe and record the current water level, and inspect it again after the chiller running for a period of time, if the water level drops obviously, please re-inspect the water pipeline leakage.
6. Adjust parameters of temperature controller.
CW-6300 series use an new intelligent controller. It works in defaulted constant temperature control mode for the low temperature end with water temperature set at 25℃ which can be adjusted as needed.
Normally users do not need to adjust the parameters. If it is necessary, please refer to page 6 , “Unit introduction and parameters adjustment.”
7. Press the ON/OFF key on the temperature control panel to start the refrigeration system (indicator light is on).

<4> Unit introduction and parameters adjustment

- (1) The unit use wire LCD temperature controller to realize more precise temperature control and stronger capacity of resisting disturbance. It supports MODBUS-485 communication with transmission distance up to 1.2km;
- (2) It has water line anti-icing function. Under standby condition, it functions when the room temperature is below 5°C;
- (3) It has water tank heating function;
- (4) It has water line actual flow monitoring function.

1. Temperature control panel introduction and parameters adjustment

(1)The control panel has LCD screen with 7 system operation buttons which are Language Switching-button (Lang), UP-button (▲), Down-button (▼), Power-button  Set-button (Set), Quick Set-button (Quick Set) and Quit-button (Quit). Turn off the chiller by pressing the Power-button for 3 sec while other operations can be completed by short press.




(2) User parameters quick-adjusting: under normal operation condition, press Quick Set-button to set the user menu. When it displays the set item, press Quick Set to enter into parameter adjustment interface. Press ▲ or ▼ to to switch the parameter items. If the parameters need to be modified, press Quick Set-button to enter into parameter values and press ▲ or ▼ to adjust it. Save the values and return to parameter quick setting interface by pressing Quit-button when the adjustment is completed. If there is no more action within 15 sec, it will automatically exit modifying status with modified parameters saved.

(3) **User menu:** under normal operation condition, press Set-button for 5 sec to show user input password interface. Input “168” by pressing ▲ or ▼, then press Set-button to enter into User menu to set the parameters. If the password is incorrect, it will quit the setting interface and turn to normal operation interface. The default password 168 must be kept well. The user menu can not be accessed if the password is forgotten and no backup password is available.

Under user menu, in parameter items interface, press ▲ or ▼ to switch the items. If the parameters need to be modified, press Set-button to enter into parameter values and press ▲ or ▼ to adjust it. Save the values and return to parameter interface by pressing Set-button and press Quit-button to quit the user menu. If there is no more action within 15 sec, it will automatically exit modifying status with modified parameters saved.

(4) **Check the history failure records:** under normal operation condition, press Set- button and ▲ for 5 sec to access password input interface. Input password “123” and confirm by pressing Set-button, it will be in failure view status if the password is correct, if not, it will quit. When the system is under failure records viewing, it will show the first failure record and code. Press ▲ or ▼ can look over the failure records and press Quit-button to quit the failure viewing status.

(5) **Restore factory settings:** under normal operation condition, press and hold Set-button and  Power-button for 10 sec to have the password input interface popped up then input password “615” to enter into administrator setting parameters restoration function, and it will display “RECOVERY SUCCESS” and turn to operation condition after 2 sec. If the password is incorrect, it will quit the password input interface and turn to operation condition.

(6) **Unit operation condition query:** the screen will display the operation conditions of the compressor, water pump and the indoor exhaust temperature parameters, etc. by pressing Quick Set-button and ▲ at the same time and release them. Press ▲ or ▼ for page turning and it will automatically exit after displaying for 5 sec.

(7) **Clock adjustment:** under normal operation condition, press Quick Set-button for 5 sec to access clock adjustment interface with time/year flashing. Press ▲ or ▼ to adjust year and confirm by pressing Quick Set-button; with time flashing, press ▲ or ▼ to adjust hour and confirm by pressing Quick Set-button; with minute flashing, press ▲ or ▼ to adjust minute and save the clock setting by pressing Quick Set- button.

(8) **Language switching:** the system default language is Chinese. For switching to English, press Lang-button and the system will change the Chinese interface to English interface as default language.

(9) **Forced refrigeration:** under normal operation condition, press ▲ or ▼ at the same time for 5 sec to activate forced refrigeration function. Press Power-button can stop the machine and cancel forced refrigeration function.

2. Detailed parameter setting is as below table

Order	Code	Set item	Range	Factory setting	Remark	Register address
1	F1	Set temp.	F6~F5/ -20~40	25	Intelligent mode / Constant temp mode	0x0401
2	F2	Temp. difference values	-15~5	-2		0x0402
3	F3	Cooling hysteresis	0.1~3.0	0.8	0.1 resolution ratio	0x0403
4	F4	Way of control	0~1	0	0 Constant, 1 Intelligent	0x0404
5	F5	The highest set temp.	(F6+1) ~40	35	Constant temp. mode	0x0405
6	F6	The lowest set temp.	1~ (F5-1)	20	Min. 1, Constant temp. mode invalid	0x0406
7	F7	Ultra-high room temp.alarm	40~50	45		0x0407
8	F8	Ultra-high water temp. alarm	1~20	10		0x0408
9	F9	Ultra-low water temp. alarm	1~60	15		0x0409
10	F10	Temp. alarm delay	0~30	5	Minute	0x040a
11	F11	Sensor failure alarm delay	0~180	10	Second	0x040b
12	F12	Water flow detection delay of machine startup	0~180	5	Second	0x040c
13	F13	Flow alarm delay	0~180	2	Second	0x040d
14	F14	Heating hysteresis	0~10	0.8	0.1 resolution ratio	0x040e
15	F15	Water pump stop delay	0~180	5	Second	0x040f
16	F16	Startup delay	0~180	30	Second	0x0410
17	F17	Compressor activate protection	0~180	90	Second	0x0411
18	F18	Turn on setting of phase sequence protection	On off	/	Single-phase OFF / three-phase ON	0x0412
19	F19	Turn on setting of external input function (startup and standby)	On off	off		0x0413
20	F20	NO and NC setting of external input function	NO/NC	NC	NO-normally opened NC-normally closed	0x0414
21	F21	External input activation delay	0~180	0	Second	0x0415
22	F22	External input standby activation delay	0~180	0	Second	0x0416
23	F23	Key lock of Chiller On/Off	0-1	1	0: lock 1: unlock	0x0436
24	F24	Self-starting after being electrified	On off	off		0x043d

NOTE:

- (1) In parameter setting status, the system runs under original parameters;
- (2) Under Constant Temperature control mode (“ F4” set at 0), water temperature is controlled by “F1”;
- (3) Under Intelligent Control mode (“ F4” set at 1), water temperature is self-adjusting according to ambient temperature. The temperature difference is controlled by “F2”.

3. Advanced parameters adjustment case

Order	Code	Set Item	Set value in case 1	Set value in case 2	Set value in case 3	T-507 Temp comptroller default setting
1	F1	Temperature setting	/	28	25	25
2	F2	Temperature Difference values	-3	/	/	-2
3	F3	Cooling hysteresis	0.5	2.0	1.0	0.1
4	F4	Way of control	1	0	0	0
5	F5	The highest set temp.	31	30	30	35
6	F6	The lowest set temp.	25	5	5	20
7	F7	Ultra-high room temp.alarm	45	45	45	45
8	F8	Ultra-high water temp. alarm	10	5	4	10
9	F9	Ultra-low water temp. alarm	10	10	14	15
10	F10	Temp. alarm delay	5	5	5	5
11	F11	Sensor failure alarm delay	10	10	10	10
12	F12	Water flow detection delay of machine startup	5	5	5	5
13	F13	Flow alarm delay	2	2	2	2
14	F14	Heating hysteresis	0.8	0.8	0.8	0.8
15	F15	Water pump stop delay	5	5	5	5
16	F16	Startup delay	30	30	30	30
17	F17	Compressor activate protection	30	30	30	30
18	F18	Turn on setting of phase sequence protection	/	/	/	/
19	F19	Turn on setting of external input function (startup and standby)	off	off	off	off
20	F20	NO and NC setting of external input function	NC	NC	NC	NC
21	F21	External input activation delay	0	0	0	0
22	F22	External input standby activation delay	0	0	0	0
23	F23	Key lock of Chiller On/Off	1	1	1	1
24	F24	Self-starting after being electrified	off	off	off	off

Case 1: cooling water temperature is controlled by intelligent mode. Requiring water temperature to be between 25°C to 31°C. When the set water temperature is 3°C lower than the ambient temperature and ambient temperature remains steady, the fluctuation will not exceed $\pm 0.5^\circ\text{C}$. There will be an alert when water temperature is 10 °C lower or higher than target. (e.g. when ambient temperature is 30.0°C, cooling water temperature is between 27.5°C to 26.5°C, if ambient temperature is up to 30.5°C, water temperature will be between 28.0°C to 27.0°C.)

Case 2: cooling water temperature is controlled by constant mode. Requiring water temperature is constant at 28°C, and the fluctuate does not exceed $\pm 2^\circ\text{C}$. The ultrahigh water temperature alarm will be on when water temperature is 5°C higher than normal temperature, and the ultralow water temperature alarm will be on when water temperature is 10°C lower than normal temperature.

Case 3: cooling water temperature is controlled by constant mode. Requiring water temperature is constant in 25°C, and the fluctuate does not exceed $\pm 1^\circ\text{C}$. The ultrahigh water temperature alarm will be on when water temperature is higher than 30°C, and the ultralow water temperature alarm will be on when water temperature is lower than 10 °C. (No matter what is the ambient temperature, the cooling water temperature is constant between 24.0°C and 26.0°C)

4. Failure warning processing mode

When alarm occurs, the failure alarm code will be displayed on the upper right corner of the LCD screen. In alarming state, the alarm sound could be suspended by pressing any button, but the alarm display remains until the alarm condition is eliminated.


5. Failure code table

Failure code	Description	Alarm phenomenon	Alarm action	Elimination method
E00	Communication failure alarm	E00 shown with alarm sound	None	Automatic clearing after mainboard and operation panel are connected well
E01	flow alarm	E01 shown with alarm sound	The compressor, condenser fans and heater shut down	Automatic clearing
E02	Ultra-high room temp.alarm	E02 shown with alarm sound	Each refrigeration part runs under usual procedures	Automatic clearing
E03	ultra-low water temp alarm	E03 shown with alarm sound	The compressor, condenser fans and heater shut down	Automatic clearing
E04	ultra-high water temp alarm	E04 shown with alarm sound	Each refrigeration part runs under usual procedures	Automatic clearing
E05	Wrong phase and lacking phase alarm	E05 shown with alarm sound	The water pump, compressor, condenser fans and heater shut down	Manual clearing
E06	Compressor overload alarm	E06 shown with alarm sound	The compressor, condenser fans and heater shut down	Manual clearing
E07	water pump overload alarm	E07 shown with alarm sound	The water pump, compressor, condenser fans and heater shut down	Manual clearing
E08	Refrigeration system high pressure alarm	E08 shown with alarm sound	The compressor and condenser fans shut down	Manual clearing
E09	Refrigeration system low pressure alarm	E09 shown with alarm sound	The compressor and condenser fans shut down	Automatic clearing
E10	Room temp. sensor failure alarm	E10 shown with alarm sound	Switched to constant temp. mode and each refrigeration part runs under usual procedures	Automatic clearing
E11	water temp. sensor failure alarm	E11 shown with alarm sound	The water compressor, condenser fans and heater shut down	Automatic clearing
E12	Ultra-low water level alarm	E12 shown with alarm sound	The unit runs normally under set values; the water pump, compressor, condenser fans and heater shut down	Automatic clearing
E13	Exhaust temp. sensor failure alarm	E13 shown with alarm sound	Each refrigeration part runs under usual procedures	Automatic clearing
E14	Ultra-high exhaust temp. alarm	E14 shown with alarm sound	Each refrigeration part runs under usual procedures	Automatic clearing

<5> Alarm and communication output

For ensuring the equipment will not be damaged when abnormal condition occurs in the chiller, it has alarm protection function.

1. Alarm and MODBUS RS-485 communication output wiring diagram.



H1, H2 and H3 are alarm signal output terminal; A, B and PE are MODBUS RS-485 communication output terminal.

2. Working condition table of alarm signal

Unit condition	Built-in buzzer of temp. controller	OUT H1、 H2	OUT H1、 H3	ILUS
Working normally	No Sound	Disconnection	Breakover	
E00、 E01、 E05、 E06、 E07、 E08、 E09、 E11	Sounds	Breakover	Disconnection	
E02、 E10、 E13、 E14	Sounds	Disconnection	Breakover	
E03、 E04	Sounds	Breakover	Disconnection	Optional
E12	Sounds	Breakover	Disconnection	Activate after output terminal delaying

Note: The flow alarm is connected to the normally open relay and normally closed relay contacts, requiring operating current less than 3A, working voltage less than 300V.

<6> MODBUS RS-485 communication function

This system adapts slave mode of MODBUS-RTU communication, 9600 baud rate, no parity checking, 8 data bit, 1 stop bit and support MODBUS-RTU 03 (Read Holding Registers) and 06 (Read Holding Registers) commands. Communication formats are as below:

1. Command format 03

Host send command

Function code	1 bytes	0x03
Initial address	2 bytes	From 0x0400 to 0x044a, From 0x0100 to 0x0108, From 0x0800 to 0x0803
Register number	2 bytes	From 1 to 10

Slave response

Function code	1 bytes	0x03
Number of bytes	1 bytes	2*N ("N" is the number of registers)
Register value	N*2 bytes	

Error

Error code	1 bytes	0x83
Exception code	1 bytes	01 or 02 or 03 or 04

For example: if the host's sending address is 1, requests 108-110 command of slave read register and send 01 03 00 6B 00 03 XX YY, thereinto, 01 as slave address, 03 as function code, 00 6B as initial address, 00 03 as register number and XX YY as the result of CRC verification.

Slave response: 01 03 06 02 2B 00 00 00 64 XX YY, thereinto, 01 as slave address, 03 as function code, 06 as number of bytes, 02 2B 00 00 00 64 corresponding to the values in 108-110 of register respectively and XX YY as verification code.

If the slave receives wrong data, return to data 01 83 01 XX YY, thereinto, 01 as slave address. 83 as error code, 01 as exception code and XX YY as check sum.

2. Command format 06

Host send command

Function code	1 bytes	0x06
Register address	2 bytes	From 0x0400 to 0x044a
Register value	2 bytes	From 0x000 to 0xffff

Slave response

Function code	1 bytes	0x86
Register address	2 bytes	From 0x0400 to 0x044a
Register value	2 bytes	From 0x000 to 0xffff

Error

Error code	1 bytes	0x86
Exception code	1 bytes	01 or 02 or 03 or 04

For example: if the host's sending address is 1, requests command of writing data 00 03 to register 2. Host send: 01 06 00 02 00 03 XX YY, thereinto, 01 as slave address, 06 as function code, 00 02 as register address, 00 03 as written data and XX YY as verification code.

Slave response: 01 06 00 02 00 03 XX YY, thereinto, 01 as slave address, 06 as function code, 00 02 as register address, 00 03 as written data and XX YY as CRC verification code.

If there is data error or communication exception, send 01 86 02 XX YY.

3. Read only parameter (sensor, current)

Read-only						
Register address	Description	Range	Default	Unit	Data resolution	Symbol
0x0100	Room temp. sensor temperature	-25 ~ 100		℃	0.1/bit	yes
0x0101	Water temp. sensor temperature(Low temp)	-25 ~ 100		℃	0.1/bit	yes
0x0102	Water temp. sensor temperature(High temp)	-25 ~ 100		℃	0.1/bit	yes
0x0103	Compressor exhaust temperature	-25 ~ 140		℃	0.1/bit	yes
0x0104	Flow of the first waterway	0.1-200		L/Min	0.1/bit	yes
0x0105	Flow of the second waterway	0.1-200		L/Min	0.1/bit	yes
0x0106	Conductivity	0.1-500		μs/cm	0.1/bit	yes
0x0107	Compressor current (Three-phase average)	0-50		A	0.1/bit	yes
0x0108	Low temp. water pump current	0-50		A	0.1/bit	yes
0x0109	High temp. water pump current	0-50		A	0.1/bit	yes

4. Read only parameter (state)

Read-only						
Register address	Description	Bit definition				
0x0800	Relay output status	MSByte	Bit7(MSb)	Retain		
			Bit6	Retain		
			Bit5	Retain		
			Bit4	Retain		
			Bit3	Retain		
			Bit2	Alarm output relay	0: Off	1: On
			Bit1	Conductivity lower limit relay	0: Off	1: On
			Bit0(LSb)	High temp. heating rod	0: Off	1: On
		LSByte	Bit7(MSb)	High temp. water pump relay	0: Off	1: On
			Bit6	High temp. refrigeration relay	0: Off	1: On
			Bit5	Compressor crankcase heating	0: Off	1: On
			Bit4	Low temp. heating rod	0: Off	1: On
			Bit3	Low temp. refrigerant solenoid valve	0: Off	1: On
			Bit2	Condensing fan	0: Off	1: On
Bit1	Compressor relay		0: Off	1: On		
Bit0(LSb)	Low temp. water pump		0: Off	1: On		
0x0801	Digital input switch status	MSByte	Bit7(MSb)	Retain		
			Bit6	Retain		
			Bit5	Retain		
			Bit4	Retain		
			Bit3	Retain		
			Bit2	Retain		
			Bit1	Retain		
			Bit0(LSb)	Retain		
		LSByte	Bit7(MSb)	Retain		
			Bit6	Retain		
			Bit5	External input	0: No input	1: Input
			Bit4	Refrigerant low pressure	0: No input	1: Input
			Bit3	Refrigerant high pressure	0: No input	1: Input
			Bit2	Spare 2	0: No input	1: Input
Bit1	Spare 1		0: No input	1: Input		
Bit0(LSb)	Water level		0: No input	1: Input		
0x0802	Alarm status	MSByte	Bit7(MSb)	Retain		

	(high 16-bit)		Bit6	Retain	
			Bit5	Retain	
			Bit4	Backup switch 2 alarm	0: Correct 1: Error
			Bit3	Backup switch 1 alarm	0: Correct 1: Error
			Bit2	Retain	
			Bit1	Retain	
			Bit0(LSb)	Retain	
			LSByte	Bit7(MSb)	Write administrator parameter error
		Bit6		Write user parameter error	0: Correct 1: Error
		Bit5		Ultra-high exhaust temp. alarm	0: No alarm 1: Alarm
		Bit4		Exhaust temp. sensor failure alarm	0: No alarm 1: Alarm
		Bit3		Low water level alarm	0: No alarm 1: Alarm
		Bit2		Ultra-low conductivity alarm	0: No alarm 1: Alarm
		Bit1		Ultra-high conductivity alarm	0: No alarm 1: Alarm
		Bit0(LSb)	High temp. system water temp. sensor failure alarm	0: No alarm 1: Alarm	
0x0803	Alarm status (low 16-bit)	MSByte	Bit7(MSb)	Low temp. system water temp. sensor failure	0: No alarm 1: Alarm
			Bit6	Room temp. sensor failure	0: No alarm 1: Alarm
			Bit5	Refrigeration system low pressure	0: No alarm 1: Alarm
			Bit4	Refrigeration system High pressure	0: No alarm 1: Alarm
			Bit3	High temp. water pump overload	0: No alarm 1: Alarm
			Bit2	Low temp. water pump overload	0: No alarm 1: Alarm
			Bit1	Compressor overload	0: No alarm 1: Alarm
			Bit0(LSb)	Wrong phase and lacking phase	0: No alarm 1: Alarm
		LSByte	Bit7(MSb)	High temp. system ultra-high water temp	0: No alarm 1: Alarm
			Bit6	High temperature system water temperature ultralow	0: No alarm 1: Alarm
			Bit5	Low temperature system water temperature ultrahigh	0: No alarm 1: Alarm
			Bit4	Low temperature system ultralow water temperature	0: No alarm 1: Alarm
			Bit3	Ultrahigh ambient temperature	0: No alarm 1: Alarm
			Bit2	High temperature system flow fail	0: No alarm 1: Alarm
			Bit1	Low temperature system flow fail	0: No alarm 1: Alarm
Bit0(LSb)	Communication fail	0: No alarm 1: Alarm			

5、Read/Write Registers(Use only when the external input function is turned off)

Register address	Description	Range	Default	Unit	Remark	Symbol
0x0804	Chiller On/Off	0-1	--		0: On, 1: Off	No

<7> Specifications

CW- 6300 Series

Model	CW-6300AN	CW-6300BN	CW-6300EN
Voltage	AC 1P 220V	AC 1P 220V	AC 3P 380V
Frequency	50Hz	60Hz	50Hz
Current	4.2-18.8 A	3.7-18.5 A	2.8-9 A
Nominal cooling capacity	7.86KW	9.5KW	8.04KW
Refrigerant	R-410a		
Precision	±1℃		
Reducer	Capillary		
Protection	Overcurrent protection for compressor, flow alarm, over temperature alarm		
Pump power	0.37~1.1KW		
Tank capacity	50L		
Inlet and outlet	Rp 1"		
Max. lift	28~53 M		
Max. flow	70 ~116 L/min		
N.W	135Kgs		
G.W	152Kgs		
Dimension	83 X 65 X 117 cm (L X W X H)		
Package dimension	95 X 84 X 136 cm (L X W X H)		

Note: The current and nominal cooling capacity could be different under different working conditions and configurations. The above information is for reference only. Please subject to the nameplate of the actual delivered product. The max. pump flow is obtained by testing the pump individually on test criteria GB/T 3216-2005.

<8>Simple troubleshooting

Failure	Failure Cause	Approach
Machine turned on but unelectrified	Power cord is not plugged in place	Check and ensure the power interface and the power plug is plugged in place and in good contact
	Fuse burnt-out	Open the electric box cover, check the protective tube, replace with spare one if necessary and check whether the power supply voltage is stable; Check and ensure the power interface and the power plug are in good contact
Flow Alarm(controller displays E01) use a water pipe directly connect to the water outlet and inlet but still without water flowing	Water level in the storage water tank is too low	Check the water level gauge display, add water until the level shown in the green area; And check whether water circulation pipe leaks
Flow alarm occurs while running with other equipment (controller displays E01), but there is water flowing and no alarm when use a water pipe directly connected to the chiller water outlet and inlet	Water circulation pipes are blocked or a pipe bending deformation.	Check water circulation pipe
Ultra-high temperature alarm (controller displays E04)	Blocked dust gauze, bad thermolysis	Unpick and wash the dust gauze regularly
	Poor ventilation for air outlet and inlet	To ensure a smooth ventilationfor air outlet and inlet
	Voltage is extremely low or astable	To improve the power supply circuit or use a voltage regulator
	Improper parameter settings on thermostat	To reset controlling parameters or restore factory settings
	Switch the power frequently	To ensure there is sufficient time for refrigeration (more than 5 minutes)
	Excessive heat load	Reduce the heat load or use other model with larger cooling capacity
Alarm for ultra-high room temperature (controller displays E02)	The working ambient temperature is too high for the chiller	To improve the ventilation to guarantee that the machine is running under 40℃
Serious problem of condensate water	Water temperature is much lower than ambient temperature, high humidity	Increase water temperature or to preserve heat for pipeline
Water drains slowly from outfall during water changing	Injection port is not open	Open the injection port